

NX calculate weight for assemblies

Watch this NX Tip Video:



This video shows how to have NX calculate weight for assemblies. You don't need an advanced assemblies license just set the right defaults and NX will calculate for you correctly.

